



Installation Instructions

- 1) First decide approximately where you would like your Sky Tunnel located in your home.
- 2) Check that the attic space is clear of obstructions above where you wish to locate the Sky Tunnel.
- 3) Measure to the centre (between the joists) and tap a small nail through the ceiling from the top. Then check you have the correct position for your Sky Tunnel from inside the room.
- 4) Using the up-stand of the ceiling frame as a template, mark the ceiling with a pencil, ensuring the nail hole is at the centre.
- 5) Cut along the pencil line on the ceiling with a keyhole saw.
- 6) Insert the ceiling frame and attach with the 2" screws and plastic lugs provided. The plastic lugs are placed on the top side of the ceiling, fasten the screws through the holes in the ceiling frame, through the ceiling and into the white plastic lugs and tighten. Finish off with the white plastic caps into the screw heads.
- 7) From the attic, choose the most direct route for the flexi-tube to reach the roof. Push back a tile to mark the location. Make sure there is a clear area of roof above your location. (*Note: also consider that Skylights work best with Southern exposure and that the shorter, straighter and tighter the flexi-tube is, the better the performance*).
- 8) Remove tiles from the roof and cut out the tile batten.
- 9) Push the stainless steel ring (with the Flexi-tube already fitted) into the underneath of the black breather frame, lining up the slots in the ring with the lugs in the breather frame.
- 10) Twist the stainless steel ring to lock it into position.
- 11) Lower the Sky Tunnel into position.
- 12) Ensure the rear portion of the Soaker Tray is underneath the tiles behind and the front portion is on top of the tiles. Gently mould the corrugated flashing at the front to match the profile of the tiles.
- 13) Re install any tiles (trim if necessary) to cover the side of the Soaker Tray.
- 14) Reach through the ceiling frame and pull the Flexi-tube through and into the room. Pull it tight and the wires will lock onto the lip at the top of the ceiling frame.
- 15) Cut the Flexi-tube off level with ceiling frame.
- 16) Fit the Flexi-tube locking ring into position with the screws provided. Be sure to line up the recess in the Flexi-tube locking ring with the recess in the ceiling frame
- 17) Fit the diffuser holder into position. Be sure to line up the magnets in the diffuser holder with the magnet locating plates in the ceiling frame.